

Vibrator Accessories – P Series Mounting Plates






Part	Dimensions		Suits	Nut Torque	
Number	Width	Depth	Model	Min (N)	Max (N)
PMP25	50	25	P25	50	72
PMP40	50	25	P40	150	174
PMP60	75	40	P60	180	230

Supplied with Nyloc Nuts and Washers

Installation Guidelines for Mounting Plates

- 1. Fully weld the plate to the wall of the hopper/bin approx. 1/3rd up from the outlet.
- 2. Mount the vibrator and secure with nuts and washers.
- 3. Tighten the nuts to the torque specified in the table.



Filter Regulator Package



Filter Regulator Package								
Flow		Port	Drain	Bracket	Gauge			
		Size						
2940	103	1/4	Auto	Neck	0-10			
LPM	CFM	or		Mount	Bar			
		1/2						

Also Stockists of Solenoid Valves, Ball Valves, Air Fitting, Airline, Nitto Fittings & Silencers



Filquip Pty Ltd

5/126 Compton Rd Underwood Qld 4119

Phone: +61 7 3208 3499 Fax: +61 7 3208 3449 Email: sales@filquip.com.au